



AZIMUTH	0°	27°	103°	178°	210°	270°	283°	340°
COMPASS QUADRANT BEARING	(due) N	N 27° E	S 77° E	S 2° E	S 30° W	(due) W	N 77° W	N 20° W