Four Stroke Compression Ignition (CI) Engine

Stroke 1: Air is introduced into cylinder through intake valve


Stroke 2: Air is compressed

Stroke 3: Combustion (roughly constant pressure) occurs and


product gases expand doing work

Stroke 4: Product gases pushed out of the cylinder through the

exhaust valve



Four-Stroke CI Combustion



SOI – start of injection

EOI – end of injection

SOC – start of combustion

EOC – end of combustion

Diesel Fuel Injection System

